


## Aluminium Cans & Paper Juice Cartons

1. Open the eko-krusher™ and insert the empty container as shown.



2. Push on the handle with the palm of your hand, until the eko-krusher™ is fully closed. Lift handle to remove the crushed container.




NOTE: Remove the cap, or pierce the side of juice cartons prior to crushing.

**eko-mania®**  
recycling products for your home™


## Steel Cans

1. Open the eko-krusher™ and insert the empty steel can as shown. OPEN END FIRST!



**BEWARE of sharp edges!**


2. Push on the handle with the palm of your hand, until the eko-krusher™ is fully closed. Lift handle to remove the crushed can\*.




\*NOTE: if you wish to reduce the can further, repeat step 1 & 2 - only this time insert the closed end of the partially crushed can first.

## Plastic Bottles

1. Open the eko-krusher™ and insert the empty bottle as shown. Remove the bottle cap.



2. Push on the handle with the palm of your hand, until the bottle is fully crushed. Replace the bottle cap\*\*. Lift handle to remove crushed bottle.



\*\* NOTE: to ensure the bottle remains fully crushed leave the cap on for a minimum of an hour. After that time the cap should be removed and recycled separately.

**!! WARNING - NOT TO BE USED WITH GLASS CONTAINERS !!**

© Copyright 2009 eko-mania® . All Rights Reserved. P/N E-M10505 rev A.